

Given the "cutting shifter" posts and all that, I felt I had to take some type of leap.



Take 1 stock shifter lever. And two chunks of metal, same thickness, about 1.5" long each



danjreed@gmail.com  
2/27/06  
hillbilly short shifter

Chop that chunk about somewhere in the middle.



danjreed@gmail.com  
2/27/06  
hillbilly short shifter

Weld the two plates to it about 1/2" or 5/8" longer or so...



danreed@gmail.com  
2/27/06  
hillbilly short shifter



danreed@gmail.com  
2/27/06  
hillbilly short shifter

Install that chunk o ugly weld into your 020 trans... and..



danjreed@gmail.com  
2/27/06  
hillbilly short shifter

Yup, its a real short shifter folks. My shift throw went from 5.6" at the top of the shifter, down to 4"...  
Does not, and cannot "hit shift linkage" or "harm syncros..".. I have a cut away trans if you don't think so...